


DOOR LOCATION: _____ DOOR NO: _____ SHEET ____ OF ____



① VERTICAL SECTION

▼ = FINISHED FLOOR



② HORIZONTAL SECTION

SAMPLE PACKAGE WIDTH INFORMATION			
PACKAGE WIDTH [UW] (*)	CLEAR DOOR OPENING [CDO] (*)	PANEL WIDTH [PW] (*)	EMERGENCY BREAKOUT WIDTH (*)
$2*[CDO] + 23 \frac{1}{8}$	$[UW]_{/2} - 11 \frac{9}{16}$ -OR- $2*[PW] - 12 \frac{7}{16}$	$[UW]_{/4} + \frac{7}{16}$	$[UW] - 2*[PW]$ - $3 \frac{1}{2}$
10'-0" [3048]	48 $\frac{7}{16}$ " [1230]	30 $\frac{7}{16}$ " [773]	55 $\frac{5}{8}$ " [1413]
12'-0" [3658]	60 $\frac{7}{16}$ " [1535]	36 $\frac{7}{16}$ " [926]	67 $\frac{5}{8}$ " [1718]
14'-0" [4267]	72 $\frac{7}{16}$ " [1840]	42 $\frac{7}{16}$ " [1078]	79 $\frac{5}{8}$ " [2022]

(*) CALCULATIONS BASED ON EQUAL PANELS, 2 $\frac{1}{8}$ " NARROW STILES, & $\frac{1}{4}$ " GLASS
(**) TO OPEN SX PANEL FLUSH WITH EDGE OF MO, USE THE FOLLOWING FORMULAS:
 $[SXPW] = [MO]_{/2} + 2 \frac{9}{16}$ | $[PPW] = [MO]_{/2} + 4 \frac{13}{16}$ | $[UW] = 2*[MO] + 13 \frac{1}{8}$